


TF-SB-10X10-26







(2) Printed Graphic Fabric Banner (Optional)















STEP 02 Connect long poles with corner poles according to labelings.



STEP 03 Slide fabric banner on frame from top and zip up at bottom.




(1) Hardware



(2) Printed Graphic Fabric Banner (Optional)



STEP 01 Connect poles according to labelings.



STEP 02 Slide fabric banner on frame from left and zip up at right.







Booth Set Assembly








(2) 180° C-Shaped Clip




x:

STEP 01 Interconnect display stands with C-shaped clips.




STEP 05 Screw light clips at top of display stands, slide lights onto them and adjust their direction.












(3) TV mount & Screw bag




(2) Fabric banner



(4) Counter top









STEP 02

To connect the poles according to the labellings




STEP 03

To install the cross bar in position




STEP 04

To wrap the fabric banner from top to bottom and zip up



STEP 05

To put the counter top in position and unzip the zippers at 2 sides and use screw for fastening from bottom



STEP 06 To install the TV mount

(1) Durable Plastic Hard Case, Aluminum Support Poles



(2) Printed Graphic Fabric Banner



STEP 01

Put hard case's top into fabric banner.



STEP 02

Insert support poles into hard case's top & bottom.



STEP 04

Wrap fabric banner from bottom to top & twist it to be smooth, lay hard case's intermediate panel on podium's top.

